

Oceanic Teak Furniture Java Backless Bench Assembly

There are just 3 parts – Seat Section / 2 x Legs (Left & Right) / 4 x Brass Bolts, 4 x Screws & 1 Allen Wrench

Tools required – Wooden or Rubber Mallet / Phillips Head Screwdriver

You will see there are coded stickers on the parts, please align the relevant stickers to make sure the furniture is assembled correctly.

You may need to use a wooden or rubber mallet to tap the sections into place and ensure they are slotted together securely.

1. Lay one leg section on its side with the holes facing up.
2. Insert the seat section making sure any stickers are lined up and ensuring it is slotted fully and securely into place
3. Place the remaining leg section on top, lining up the holes and tap securely & fully into place.
4. Carefully rotate the bench and stand on its legs – You may need help at this point – Make sure the parts are still securely & fully in place.
5. Insert the brass bolts into the relevant holes on each side and hand tighten, then using the Allen wrench fully tighten each bolt.
6. Lay the bench over onto its back and screw the 4 screws through the pre-drilled holes (2 on each side) in the seat section and into the leg sections.

